appSP06X

aqprox!

# Speaker System with Docking for iPod or iPhone

## Guía de usuario
## User guide



# Capítulo 1. Introducción

Gracias por elegir el altavoz portátil para iPod y iPhone APPSP06X.

## Descripción del producto

El altavoz portátil APPSP06X de Approx te permite disfrutar de una potencia de 6 vatios para tu iPhone o iPod. El APPSP06X se adapta a todas sus necesidades ya que está dotado de numerosas funciones y de mando a distancia.

¡Disfruta del mejor sonido allá donde vayas!

# Capítulo 2. Contenido del embalaje

- Guía de usuario
- Cable auxiliar de audio
- Adaptador de corriente
- Control remoto

Asegúrese de que su embalaje contiene los elementos descritos arriba. Si encuentra que falta algún elemento o está dañado, por favor, contacte con su distribuidor.

# Capítulo 3. Requisitos del sistema

- Una toma de corriente
- iPod/iPhone o dispositivo multimedia con salida auxiliar de audio

# Chapter 4. Preparación para su uso

## Conexión de la fuente de alimentación

Esta unidad se ha diseñado para funcionar con el adaptador de corriente suministrado. La conexión de este sistema a cualquier otro adaptador de corriente puede causar daños en el sistema. Siga los siguientes pasos para utilizar el adaptador. Desenrolle el cable de alimentación del adaptador en toda su longitud. Conecte el conector a la toma DC IN de la parte trasera de la unidad. Asegúrese de que el adaptador de CA esté totalmente insertado en la toma de corriente eléctrica. Para apagar la unidad completamente, desenchufe el adaptador de alimentación de la toma de pared.

1. No conecte o desconecte el cable de alimentación en las manos mojadas

2. Por favor, desconecte el enchufe de la toma de corriente si el aparato no va a ser utilizado durante un largo periodo de tiempo.

## Instalación y cambio de la pila del control remoto

El mando a distancia requiere una “pila del tipo CR2025” de 3 voltios, litio (incluida). Para extender la vida útil de la batería original que hemos insertado una pequeña pestaña trasparente separadora de plástico entre la batería de litio y la terminal de la batería. Usted debe quitar este separador antes de utilizar el mando a distancia.

Para sustituir la pila, haga lo siguiente:

1. Deslice el soporte de la pila del control remoto.

2. Coloque una batería de 3V CR205 en el soporte de la batería, observe las marcas de polaridad, si la batería no está colocada correctamente, el mando a distancia no funciona. Deshágase de las baterías usadas en un lugar destinado para tal cometido.



3 . Inserte el soporte de la batería en el compartimento de la batería.

4 . Apunte el control remoto directamente al sensor (IR) del panel frontal. No coloque ningún objeto entre el control remoto y el sistema durante la operación de la unidad.

# Capítulo 5. Descripción de las partes

## Panel superior, frontal y trasero






1. Indicador de encendido
2. Play / Pausa
3. Retroceder
4. Avanzar
5. Volumen menos
6. Volumen más

7. Selección entre (iPhone / Auxiliar)
8. Conector para iPhone
9. Indicador encendido / standby
10. Indicador modo Aux. iPhone.
11. Indicador modo Aux.
12. Indicador modo sonido apagado
13. Sensor IR
14. Giro 90 grados
15. Interruptor de encendido (ON/ OFF)
16. Entrada Auxiliar Jack 3.5mm
17. Entrada DC 6V input

## Remote control




1. Standby / Encendido
2. Modo iPhone
3. Modo Auxiliar
4. Menú

5. iPod menu scroll subir
6. iPhone retroceder
7. Entrar o aceptar
8. Shuffle boton
9. iPod menu scroll bajar
10. Sonido apagado
11. Volumen menos
12. iPhone Play / Pausa
13. Equalizador
14. Parar
15. iPhone avanzar
16. Repetir
17. Volumen más

# Chapter 6. Instrucciones de uso

## Operaciones básicas

1. Seleccione el interruptor principal situado en la parte posterior de la unidad a la posición “ON”, la unidad estará en modo de espera. El indicador de encendido / espera, se enciende (color rojo).

2. En el modo de espera, presione el botón POWER / STANDBY en la unidad o del control remoto para encender la unidad.

3. En el modo de encendido, seleccionar la fuente de deseada con el botón SOURCE en la unidad o IPHONE / botón AUX en el control remoto para seleccionar el modo AUX y IPHONE.

4. Ajuste el nivel de volumen principal pulsando el botón de volumen + / -. Botón o mantener el control de volumen en la unidad El indicador POWER parpadea para mostrar el

volumen es bajo el ajuste.

5. Pulse el botón MUTE en el mando a distancia para interrumpir el sonido inmediatamente. La reproducción continuará sin sonido. Para activar la reproducción de sonido, puede pulsar el botón MUTE o ajustar los controles de volumen para continuar.

## Funcionamiento con iPhone / iPod

Esta unidad es compatible con el iPhone 4, iPhone 3G y el iPod touch, y los tipos más diferentes de iPod que tiene 30 pines, etc

Usted puede escuchar la música del iPod conectado a través del potente altavoz del reproductor. También actúa como un cargador de batería del iPhone / iPod. Mientras tu iPhone / iPod dock esté conectado a la unidad, que recargará automáticamente la batería hasta que esté completamente cargada. Esta unidad está diseñada una estación de acoplamiento universal para iPod inserta propia cuna.

Pulse el botón STANDBY para encender la unidad, a continuación, pulse el botón SOURCE para seleccionar el modo iPod (el iPod no debe estar en una funda para el iPod) El iPod se reproducirá de forma automática e iniciará la carga inmediatamente una vez que el iPod está conectado. Pulse el botón de PLAY / PAUSE para pausar la reproducción durante la reproducción. Pulse el botón otra vez para reanudar la reproducción.

Seleccione la música deseada, fotos o video, etc, como de costumbre. También puede pulsar el botón Siguiente o Anterior en la unidad o del control remoto para saltar a la canción siguiente o anterior.

## Usando el sistema de menú del iPod

1. Seleccione el modo de iPod presionando el botón SOURCE.

2. Con cuidado, inserte la unidad de iPod en el dock.

3. Pulse el botón MENU una vez en el mando a distancia para entrar en el sistema de menú del iPod.

4. Pulse el botón arriba/abajo del mando a distancia para navegar por las diversas características del sistema de menú del iPod como lo haría al utilizar los botones de control del iPod.

5. Pulse el botón ENTER en el mando a distancia para confirmar su selección.

## Modo auxiliar

Usted puede escuchar el sonido de un dispositivo externo conectado a este dispositivo a través del altavoz interno.

Conecte su dispositivo a la entrada auxiliar, como reproductores MP3, reproductores portátiles de CD, móviles.

La función auxiliar sólo se puede utilizar cuando hay una conexión hecha a la entrada AUX IN.

Pulse el interruptor de AUX en el dispositivo o en el control remoto para seleccionar la fuente auxiliar.

# Capítulo 4. Instalación

- Coloque su altavoz APPSP06X sobre una superficie estable
- Conecte el cable de corriente
- Coloque el interruptor en la posición ON
- Coloque con cuidado su iPhone o iPod sobre la ranura central

# Capítulo 5. Soporte técnico

Para más información sobre la instalación y configuración de este producto diríjase a nuestra web www.approx.es (sección soporte).

# Chapter 1. Introduction

Thank you for choosing the Ipod and Iphone portable speaker APPSP06X.

## Product description.

The Approx speaker APPSP06X lets you enjoy 6 watts of power for your iPhone or iPod. The APPSP06X suits your needs because it is equipped with numerous features and remote control.

Enjoy great sound wherever you go!

# Chapter 2. Package contents

- User Guide
- Auxiliary audio cable
- Power adapter
- Remote control

Make sure your package contains the elements described above. If you find something is missing or damaged, please contact your dealer.

# Chapter 3. System requirements

- One power socket
- iPod / iPhone or multimedia device with auxiliary audio

# Chapter 4. Preparation for use

## Connecting power source

This unit was designed to operate with AC adaptor. Connecting this system to any other power source may cause damage to the system. Take the following steps to use the adaptor. Unwind the power cord of the adaptor to its full length. Connect the DC plug to the DC in socket on the rear of the unit, and then pug the adaptor to the AC outlet (100-240V~50/60Hz). Make sure the AC adaptor is fully inserted into the mains power outlet. The set is now connected and ready to use.

To switch the unit off completely, withdraw the power adaptor from the wall outlet.

1. Do not plug or unplug the power cable in wet hands

2. Please disconnect the mains plug from the AC outlet if the appliance is not going to be used for a long period of time.

## Installing and replacing the battery of the remote control

The remote control requires one"CR2025 type" 3-Volt lithium battery (included). To extend the life of the original battery we have inserted a small clear plastic spacer tab between the lithium battery and the battery terminal. You must remove this battery spacer tab before you use the remote control. To remote the table, pull it in the direction of the arrow in the illustration,

As shown:

If the operation of the remote control becomes unsatisfactory, replace the original battery with a new 3-volt lithium battery.

1. Slide out the battery holder from the remote control case.



2. Place one 3V CR205 battery in the battery holder, observing the polarity marking, if the battery is placed incorrectly, the remote control will not work. Dispose of the old battery properly. Do not leave it lying around where a young child or pet could pay with or swallow it.

Battery may explode or leak if mistreated, Do not attempt to reaching it or disassemble it, Do not dispose of the old battery in a fire.

3. Insert the battery holder into the battery compartment.

NOTE: Please remove all of the batteries to prevent damage or injury from possible battery leakage if the unit will not be used for a long period of time. Use only the specified size and type of battery.

## Using the remote control to operate the product:

Aim the remote control directly at the remote control sensor (IR) on the front panel. Don't put any objects between the remote control and the system while operating the unit.

# Chapter 5. Location of controls and indications

## Front and top panel






1. Power / Standby button
2. Play / Pause button
3. Skip Previous button
4. Skip Next button
5. Volume control
6. Volume control
7. Source(iPhone / Aux selection) button
8. iPhone dock connector
9. Power Standby indicator
10. iPhone mode indicator
11. Aux mode indicator
12. Mute indicator
13. IR sensor
14. Swivel speaker for 90 degree
15. Main Power Switch (ON/ OFF)
16. Aux-in Jack connection
17. DC 6V input

# Remote control




1. Standby / ON button
2. iPhone mode button
3. Aux mode button
4. MENU button
5. iPod menu scroll up button
6. iPhone Skip previous button
7. Enter button
8. Shuffle button(Random)
9. iPod menu scroll down button
10. Mute button
11. Volume button
12. iPhone Play / Pause button
13. EQ button
14. STOP button
15. iPhone Skip Next button

16. Repeat button
17. Volume button

# Chapter 6. Operating instructions

## Basic operations

1. Select the main power switch located at the back of the unit to “ON” position, the unit will be in Standby mode. The Power / Standby indicator will light up (red color).

2. In the Standby mode, press the POWER / Standby button on the unit or the remote control to turn on the unit.

3. In Power ON mode, select sound source by SOURCE button on the unit or IPHONE / AUX button on the remote control to select IPHONE and AUX mode.

4. Adjust the main volume level by pressing the Volume +/- button or hold the volume control on the unit .The POWER indicator will flash to show the volume is under adjustment.

5. Press the MUTE button on the remote control to interrupt sound reproduction instantly. The playback will continue without sound. To activate sound reproduction, you can press the mute button again or adjust the volume controls to resume.

## Operating the iPhone

This unit is compatible with iPhone 4, iPhone 3G and iPod touch, and most different kinds of iPod which has 30 pin connector, etc. You can listen to the music of the docked iPod through the powerful speaker of the player. It also acts as an iPhone / iPod battery charger. While your iPhone /

iPod dock to the unit, it will automatically recharge until fully charged.

This unit is designed a universal docking station for iPod own cradle inserts. Before plugging your iPod into the dock, snap the suitable dock adaptor int the dock to the product, All iPod model with 30-pin dock connector as below: Nano 1/2/3/4th and iPod 5th generation (Video) 6th generation, iPod touch and iPod classic.

1. In power on mode, press the STANDBY button to switch on the unit, then press the SOURCE button to select iPod mode.

2. Carefully insert you iPod into the iPod dock well. (The iPod must not be in a iPod case) The iPod will start playing automatically and starting charging immediately once the iPod is connected. Press the PLAY/PAUSE button to pause playback during the playback. Press this button again to resume playback.

3. Select your desired music, photos or video, etc and lay the connected iPod as usual. You can also press the NEXT or Previous button on the unit or remote control to skip to the next or previous music, or press and hold the button to search within a playing track at high speed to locate a specific musical passage.

4. In power on mode, the iPod could be charged in all modes if it is docked.

1. Use the correct iPod dock adaptor for your model, taking care not to damage the connecting pins.

2. Always ensure care is taken when inserting or removing your iPod from the connector.

## Using the iPod menu system

1. Select the iPod mode using the SOURCE switch.

2. Carefully insert your iPod unit into the dock.

3. Press the MENU button once on the remote control to enter the iPod menu system.

4. Press the up/down button on the remote control to navigate the various features of the iPod menu system as you would when using the iPod control buttons.

5. Press the ENTER button on the remote control to confirm you selection.

## Auxiliary in operation

You can listen to the sound of the connected external device through your speaker. Connect the audio output socket of your auxiliary sound source like MP3 players, Portable CD players and older non-dock able iPod(Except iPod shuffle 3rd gen.) player to the AUX IN socket on the back panel of unit

DON'T FORGET! The auxiliary function can only be used when there is a connection made to the AUX IN socket from another source.

DON'T FORGET! The connection cable is included.

1. Press the SOURCE switch or AUX on the remote control to select the AUX function.

2. Turn your auxiliary source ON and operates it as usual. The sound from the auxiliary source can be heard through

the speakers.

3. Adjust the volume level to your desired listening level.

## Chapter 7. Installation

- Place your APPSP06X speaker on a stable surface
- Connect the power cord
- Turn the switch on the ON position
- Carefully place your iPhone or iPod on the central slot

## Chapter 8.Technical support

For more information on installing and configuring this product go to our website www.approx.es (support section).

Importado por / Imported by:
APPROX IBERIA S. L.
CIF: B-91202499

Soporte técnico / Technical support:
**soporte@approx.es**

MADE IN CHINA

El contenido de esta guía está
sujeto a errores tipográficos

The content of this guide is
subject to typographical errors

www.printyourideas.com